

COPILOT® TRUCK™

Truck Navigation Software for Magellan RoadMate® 1470 and 1700 GPS Quick Start Guide



www.copilotlive.com/magellan

Getting Started


CoPilot® Truck™ upgrades your Magellan RoadMate® GPS Navigator into a professional truck navigation system.



Before you begin

- Switch on your Magellan RoadMate GPS device.
- If your Magellan RoadMate GPS has a memory card, please remove it and replace it with the supplied CoPilot Truck microSD memory card.

Note: The CoPilot Truck microSD card can be found in the supplied SD card adaptor.



The CoPilot Truck microSD card contains truck navigation software and maps of USA and Canada.

Memory card required at all times when using CoPilot Truck on your Magellan RoadMate GPS.

- CoPilot Truck will automatically start.
-



Magellan RoadMate GPS Device

Please refer to your Magellan RoadMate GPS user manual for details on switching your device on/off, inserting a memory card and charging the device's battery.



First time setup

The first time CoPilot Truck starts on your Magellan RoadMate GPS you will be asked to:

- Select your preferred language for on-screen text and voice guidance.
 - Choose between **Miles** and **Kilometers** for the unit of measurement used in maps and instructions.
 - Review and accept the Safety Warning for CoPilot Truck.
-



Tips and Tricks

CoPilot Truck has lots of great features. To help you get to know them, view the Tips and Tricks at start up. To see more, scroll forwards or backwards.

You are now ready to begin navigating.



First trip



Entering an Address

CoPilot Truck uses GPS satellites to calculate your exact position so you don't have to enter your starting point.

Simply enter your destination and CoPilot Truck will guide you there, providing detailed dock-to-dock instructions.

- Tap **Menu** ► **Destination** ► **Address**.
- Enter the city/town name of your destination.
- Select the correct city from the list. Scroll down to see more options matching what you have typed.
- Enter the first three or four letters of the street name. Select the correct street from the list.

- Enter the house number and select **Finish**, or just select **Finish** to skip this step.
 - A screen will then appear, showing you a map of the route. Select **Drive** to begin navigating your route.
-



Truck Specific Navigation Settings

You can adjust CoPilot Truck's routing to suit the type of vehicle you are driving or even the type of load you are transporting.

CoPilot Truck automatically avoids truck restricted routes, helping you arrive at your destination safely and on schedule.

— Select Menu ► Settings ► Routing.

Here you can:

- Choose your **Vehicle type**.
- Select a **Routing Type**.
- Decide how to handle **Toll Roads**.
- Choose standard truck routes, including **53 ft Trailer** and **National Network**.
- Set **HazMat Routing** for specific types of load.
- Adjust your routing based on the height, width, length and weight of the truck you are driving.

There's more you can do with CoPilot Truck:

Plan a trip with multiple destinations.

— Select Menu ► Plan or Edit Trip.

Once you have planned a trip with more than 3 stops, select **Optimize** to reorder your stops for the most efficient route.

Set and save your Work address for quick and easy route planning.

— Select Menu ► Destination ► Work.

Calculate the estimated fuel costs for a trip.

- Select Menu ► Plan or Edit Trip ► Options ► Show Estimated Fuel Costs.
Key in the information requested to complete the calculation.

You can go further with CoPilot Truck.

On the move



Change the Driving View

You can choose from a number of different driving views including 2D, 3D and Driver Safety.

— **Select Menu** ► **Driving Views.**



Search for a Point of Interest

Running low on fuel? Need to find the nearest rest area or truck stop? CoPilot's truck specific POIs make it easy for you find the useful places you need on your route.

— **Select Menu** ► **Nearby POI.**



Set Warnings

If you turn onto a truck restricted road, CoPilot Truck will warn you and can automatically calculate the best alternative route for your journey.



Take a Detour

Once you're on the move, unexpected road conditions could require you to take a detour to reach your destination.

— **Select Menu** ► **Detour.**

Support

COPILOT[®] TRUCK[™]



Register

Take a moment to register your CoPilot Truck software at www.copilotlive.com/register

By registering, you'll be the first to hear about new CoPilot products and updates.



Help and Support

To learn more about using CoPilot Truck, download the CoPilot Truck user manual at: www.copilotlive.com/support

Our FAQs section provides answers to the most frequently asked questions to help you get started and get the most out of your CoPilot Truck. Read the FAQs at: www.copilotlive.com/support

Call a member of our technical support team to receive professional and friendly assistance for your CoPilot Truck navigation software.

Telephone: 408 916 9128

Our technical support team is available Monday to Friday 9:00am to 5:30pm EST.

COPILOT® TRUCK™



MAGELLAN®



ALK
ALK Technologies

CoPilot® Truck™. © Copyright 2009. ALK Technologies Inc. All rights reserved.